



Freelander 2006 2.2Ltr TD4

Engine Parts

Description	Vin. Variation	Part Number	Notes
Engine O/Haul Gasket Kit			
VRS Gasket Kit			
Cylinder Head		LR005990	
Cylinder Head Bolts		LR001222	(10)
Exhaust Valves		LR001237	
Inlet Valves		LR004290	
Lifters		LR004168	-16
Pistons		LR001268	
Piston Rings		LR005377	
Main Bearings Upper		LR000667	(5)
Main Bearings Upper		LR001235	(5)
Main Bearings Lower		LR001254	Blue
Main Bearings Lower		LR001255	Black
Main Bearings Lower		LR001256	Green
Main Bearings Lower		LR001257	Red
Main Bearings Lower		LR001258	Yellow
Big End Bearings		LR005378	Green
Big End Bearings		LR005379	Yellow
Big End Bearings		LR005380	Blue
Oil Pump		LR004292	
Valve Stem Seals		LR001242	
Head Gasket		LR001218	1 Hole 1.25mm
Head Gasket		LR001219	2 Hole 1.30mm
Head Gasket		LR001220	3 Hole 1.35mm
Head Gasket		LR001221	4 Hole 1.40mm
Inlet Manifold Gasket		LR005364	
Exhaust Manifold Gasket		LR001315	
Rocker Cover Gasket		LR005375	L Shape
Rocker Cover Gasket		LR005376	Round (2)
Adapter Plate Head Gasket Ctr		LR002834	
Front Crank Seal		LR000673	
Rear Crank Seal		LR000674	
Sump Gasket			
Cam Seal		LR000659	
Timing Belt		LR004257	
Engine Mount	>7H020846	LR001179	

Engine Mount	7H020847>	LR006277	Manual
Engine Mount	7H020847>	LR006538	Auto

Engine Electrical Parts

Description	Vin. Variation	Part Number	Notes
Glow Plugs		LR001302	
Alternator		LR001200	With Heated W/Screen
Alternator		LR002899	W/O Heated W/Screen
Starter Motor	>7H048583	LR003468	Manual
Starter Motor	7H048584>	LR007372	Manual
Starter Motor	>7H048583	LR003469	Auto
Starter Motor	7H048584>	LR007373	Auto

Engine Cooling Parts

Description	Vin. Variation	Part Number	Notes
Radiator		LR000583	Manual
Radiator	>7H037400	LR002641	Auto
Radiator	7H037401>	LR006715	Auto
Radiator Cap		LR000243	
Top Radiator Hose	>7H021214	LR003540	
Top Radiator Hose	7H021215>	LR006135	
Lower Radiator Hose		LR005300	Manual
Lower Radiator Hose	>7H025018	LR005293	Auto
Lower Radiator Hose	7H025019>	LR006993	Auto
Water Pump		LR001309	
Water Pump Gasket		LR001310	
Viscous Coupling		LR002660	Heavy Duty
Viscous Coupling	>7H043352	LR002661	STD
Viscous Coupling	7H043352~8H000001	LR006992	STD
Thermostat		LR001312	
Thermostat Gasket		LR004161	
Expansion Tank		LR004080	

Fuel Parts

Description	Vin. Variation	Part Number	Notes
Fuel Pump		LR005620	With PTC Heater
Fuel Pump		LR005622	With Fuel Fired Heater
Air Flow Meter		MHK501040	

Brake, Suspension and Hub Parts

Description	Vin. Variation	Part Number	Notes
Brake Master Cyl.	>7H040933	LR001050	
Brake Master Cyl.	7H040934>	LR007378	
Front Disc Rotors		LR000571	
Rear Disc Rotors		LR001018	
HUBS			
Front Hub		LR003157	
Rear Hub		LR001127	
Rear Hub Bearing		RFC000010	
Suspension			
O/S/F Shock Absorber		LR001139	
N/S/F Shock Absorber		LR001141	
O/S/R Shock Absorber		LR005573	
N/S/R Shock Absorber		LR005574	

Drive Train

Description	Vin. Variation	Part Number	Notes
Front Propeller Shaft	>7H036404	LR001157	
Front Propeller Shaft	7H036405>	LR006959	
Front Diff Pinion Seal		LR003152	
Rear Diff Pinion Seal		LR002883	

Steering Parts

Description	Vin. Variation	Part Number	Notes
Power Steering Pump	>7H021724	LR005658	
Power Steering Pump	7H021725>	LR006462	
N/S/F Tie Rod End		LR002609	
O/S/F Tie Rod End		LR002610	
Steering Damper			

Manual Transmission Parts >7H021724

Description	Vin. Variation	Part Number	Notes
Clutch Master Cylinder	>7H040933	LR000580	
Clutch Master Cylinder	7H040944>	LR007159	

Slave Cylinder		LR001375	
Clutch Kit		LR004322	
Clutch Drive Plate			
Clutch Pressure Plate			
Release Bearing.		LR000251	

